JNC



JNC IPX2 防水暖爐
JNC IPX2 Water-resistant Heater

使用説明
User manual

JNC-PBHTHK-WH

Catalogue

Notice Before Use ——— P. 1

Safety Instructions ——— P. 2 - 3

Product Structure ——— P. 4

Operating Instructions ——— P. 5 - 6

Installation ——— P. 7 - 10

Instruction for using at bathroom ——— P. 11

Cleaning & Maintenance ——— P. 12

Troubleshooting ——— P. 13

Product Specification ——— P. 13

Warranty Policy ——— P. 14 - 15

ENG

Notice Before Use

Before using this product, please read and follow the basic safety precautions as below:

— This product is intended for household use only.
— This product is not intended for use by children and other persons whose physical, sensory, or mental capabilities or lack experience and knowledge prevents them from using the product safely without supervision or instruction by a responsible person to ensure that they can use the product safely.
— Children should be supervised by the responsible person to ensure that they do not play with the product.
— Please ensure the power outlet meets this product's requirement.
— Do not immerse the product into water or other liquid.
— Turn off the power and unplug from the socket before cleaning. Use damp cloth to wipe the exterior, do not splash water. Do not use alcohol, benzene or paint thinner to clean this product.
— After cleaning and maintenance, please wait until it is fully dry before powering up.
— When not in use for a long time, please unplug the power cord.

Safety Instructions

— To avoid overheating, do not cover the heater.
— This product is suitable for indoor use only, not for outdoor use.
— Please properly dispose of the packaging materials and small articles, keep them away from infants or children to avoid any accident.
— Do not touch the plug or product with wet hand. Do not use the product with bare feet to prevent electric shock or other injury.
— Do not leave the product unattended when it is powered on.
— Turn off the power and unplug from socket when not in use.
— Do not use the method of plugging (unplugging) the power cord to replace the power switch on and switch off.
— To prevent circuit overload, please do not insert other electrical appliances in the same socket.
— Please use grounded socket to prevent risk of electric shock.
— Do not pull the cable to disconnect the product from the power socket, always grasp and pull the plug to disconnect.
— Keep the cable away from the hot surface, sharp edge or avoid being squeezed.
— Do not use the cable to drag or move the product.
— Do not use the product if the cable or power plug is damaged or loosen when inserted into the power socket, in order to avoid risk of electric shock or fire.
— Do not use the product if it has been dropped or if there is visible damage.
— If there is any technical trouble or abnormal reaction, stop using the product and unplug it immediately to prevent further danger.
— For safety reasons, do not attempt to dissemble, fix or perform other changes to the product. Please contact the dealer or customer service for examination and repair.
— Do not place the product close to fire or near flammable, perishable materials (such as gasoline) to avoid fire hazard.

— Do not place or operate the product close to explosive or in places with heavy dust to avoid explosion.
— Do not use the product in the immediate surroundings of a bathtub, a shower or swimming pool. The product should not be placed on desk/ floor when used in the bathroom.
— Always place the product on a horizontal and stable surface, or fix it on the wall, as applicable.
— Do not immerse the product in water.
— It is strictly forbidden to insert thin metal wires or other foreign objects into any holes in the machine to avoid electric shock accidents.
— When the product is in use, the power cord should be placed at the back of the body. Putting it in front of the body will cause it to overheat and be damaged.

Product Structure



① Indicator light
② Handle*
③ Knob
④ Air outlet
⑤ Hook
⑥ Filter mesh

* Handle can be rotate up to 140° and the maximum load bearing capacity is 1kg.

Operating Instructions

Power on

1. Plug in the power plug and turn the knob to select between the three functions, Fan, Low Heat and High Heat.
2. The indicator lights up when in operating mode.



Power off

1. Turn the knob to the ⏻ position.
2. Unplug the power plug and put the product away after it cooled down.

Note:
Suggest to switch to Fan mode for 15-30s before power it off,
to prolong the life of the heater.

Overheat protection

— The temperature control element will cut the power off if internal temperature exceeds safety level, which may cause by improper positioning or abnormal use of the product.
— Once cooled down and abnormality corrected, the product can resume to normal use.
— Maintain a distance of at least 50 cm between the air outlets and walls or any other objects.



Installation

— The product must be mounted on wall when used in the bathroom. It can be placed on the desk/floor or mounted when used in living or bedroom.
— Leave enough space on all sides to allow adequate ventilation.

A. Desk/Floor

Place the product on a level surface, and sway the handle to the back.



Note:
— Maintain a safe distance and do not place near flammable materials.
— Do not use around bathtub, shower head or swimming pool when using this method .

B. Hook-mounting

1. Hang the product onto the towel rack or rail.
2. Sway the handle down when needed.



Note:

— Handle max. load bearing capacity is 1kg.

— Keep the distance of at least 50cm between product and the sidewall or any other objects. The minimum height above ground should be at least 1.5m.

C. Wall mount

1. Use the coordinate sheet to the mark position.
2. Use an electric drill to drill two 0.6cm holes (0.2 - 0.25cm in depth) on the wall with a horizontal distance of 16.5 cm.



3. Insert the screw plugs into the holes.
4. Insert the screws into the screw plugs and secure it.
5. Hang the product on the screws through matching the wall-mount holes at the back of the hook. Move the product slightly to the left to secure it.





Note:

— It should be at least 60cm away from the water source.

Instruction for using at bathroom

1. The product must be fixed on the wall.
2. The product can only be installed beyond the colored area in the picture.
3. It must be installed so that knob and other parts of product cannot be reached by a person who is in bathtub or shower.
4. Do not touch with wet hand.





Cleaning & Maintenance

Surface & Air outlet

1. Unplug the appliance and let it cool down before cleaning.
2. Clean the surface and air outlet with a damp cloth.
   Do not use gasoline, thinner, or corrosive detergent or solvent.
3. Do not rinse directly with water.

Filter Mesh

1. Remove the mesh by gently pulling it upward.
2. Wiping off the dust and hair on the filter, rinse with water and let it dry.
3. Install the mesh back to the product.



Troubleshooting

Problem	Reason	Solution
Not functioning. The indicator light is not on	Plug not inserted properly	Check whether the plug is inserted into the socket correctly.
	Product not switched on	Check if the knob is turned to on position. (Please refer to P.5)
Stopped suddenly	Product is overheat	It should be used after the heater is cooled. Turn it off and let it cool down, check if there is abnormal use.(Please refer to P.6)

Product Specification

Model:	JNC-PBHTHK-WH
Rated voltage:	220 - 240V~
Product frequency:	50 - 60Hz
Rated input power:	Fan 35W Heat 1100W / 1900W
Heating element:	PTC
Length of power cord:	2.5 m
Product size:	37.2 x 29.5 x 13.7 cm
Net weight:	1.76kg
Country of origin:	China

CB IPX2 

Warranty Policy

Model Number: JNC-PBHTHK-WH

Thank you for being our patronage. For warranty service, please read the following carefully:

1. Our Company provides a two-year warranty service from the date of purchase.
2. Customers please bring along the product to our Service Centre during our operating hours and collect it thereafter. On-site service cannot to be provided by our Company.
3. For the use of warranty services, customers are required to present the valid original purchase receipt, fax or photocopies cannot be accepted. Repairing fee will be charged if customers fail to present the above document.
4. Warranty covers only the hardware of the product's main body. All other accessories are not covered within the warranty terms, such as power cable and external cover (for accessories items, please refer to product manual)
5. All parts replaced within the warranty period are properties of our Company. We reserve the right to handle those parts at our own discretion.
6. Warranty will no longer be valid under the following circumstances, and our Company reserves the right to provide repairing service and or to demand charges for such services:
   — Products that had been used for industrial or commercial purpose.

— Products that had been modified or repaired by person(s) other than service facility anthorized by our Company .
— Damages caused by mishandling of products, such as applying wrong voltage, manual destructions, or any usages that contradict with the instructions stated in the User Manual.
— Damages caused by sand, liquid, natural disaster or accident.
— If the model number, item code or rating label attached with the product has been erased or modified.

7. Our Company will not be responsible for any indirect or consequential loss, loss of profits or loss of data.
8. Warranty sevice is effective only within Hong Kong SAR.
9. We reserve the right to issue or terminate this warranty service. For exceptional cases, subject to the result of our investigation, we reservethe right to terminate the warranty service.
10. We reserve the right to modify the terms of this warranty policy.

100 Enterprises International Group Company Limited

Should you have any enquiries, please feel free to call 100 Customer Service hotline: (852) 2342 9712, or by email to cs@jnc.com.hk or visit our 100 Customer Service Center during business hours:

Address : Flat 403, 4/F., Shiu Fat Building, 139 — 141 Wai Yip Street,
Kwun Tong, Kowloon, Hong Kong
(Ngau Tau Kok MTR Station B6 Exit)

目錄

注意事項 ——— P. 19

安全需知 ——— P. 20

產品結構 ——— P. 21

使用說明 ——— P. 22 - 23

安裝說明 ——— P. 24 - 27

浴室使用說明 ——— P. 28

清潔及保養 ——— P. 29

排解疑難 ——— P. 30

產品規格 ——— P. 30

保養條款 ——— P. 31 - 32

注意事項

使用本產品前，請遵循以下基本的安全預防措施：

一本產品僅供家居使用。
一本產品不能讓肢體不健全、感覺或精神上有障礙或缺乏相關經驗或知識的人（包括兒童）使用，除非有負責他們安全的人對他們使用本產品進行監督或指導。
一孩童應受監護，以確保孩童不嬉玩電器。
一使用前請確認當前使用電壓與產品要求電壓範圍相符合。
一請勿把產品浸入水中或其它液體中。
一請勿使用其它非專屬配件或私自拆卸、維修、改裝本產品，以免發生危險。
一清潔本產品時，請拔出電源插頭，可用含少許中性洗滌劑的軟布輕擦，然後抹乾。禁止用水直接沖洗機身，不要用酒精、苯或塗料稀釋劑塗抹在本產品上。
一清潔保養後，一定要等到充分乾爽才能通電**使用。**
一長期不用時請將電源線插頭拔下。

安全需知

一為避免過熱，禁止覆蓋加熱器。
一本產品只適宜室內使用，不宜在室外使用。
一請妥善處理本產品的包裝材料和插頭護套等細小物品，使其遠離嬰幼兒，以免誤食等而發生意外。
一請勿用濕的手接觸插頭或產品機體，或赤腳使用產品，以防觸電！
一產品在接通電源期間，不可處於無人看管的狀態。
一產品在無人使用情況下，應關閉電源，以免發生危險。
一禁止用插拔電源線插頭的方法代替功率開關的開機和關機。
一為防止電路過載，請不要在同一插座上使用其他電器。
一請確保所使用的電源插座有效接地，否則可能有觸電的風險。
一為避免危險，請用手抓住插頭後拔出，請勿直接拉扯電源線；小心門縫夾擠或鋒利物摩擦，遠離熱源。
一請不要拉扯電線以移動產品。
一當電源線或插頭有損壞或插入家用電源插座出現鬆動時，請勿使用！否則有觸電或火災的危險。
一當發生異常或故障請立即停止使用並拔出電源插頭，以免發生危險。
一如產品曾掉落或發現明顯損毀，請立即停止使用。
一為避免危險，禁止自行更換維修，請必須聯繫或交給銷售本產品的經銷商或授權的售後服務部門的專業人員來維護。
一不要讓產品靠近易燃易爆物品（如汽油），否則可能發生火災或爆炸的危險。
一禁止在有爆炸危險的區域或有嚴重粉塵的地方運行本產品。
一禁止在有易落下懸掛物、易受衝擊或擺放不穩定的地方使用。使用產品時應放置平穩，或以指示穩固懸掛牆上，請不要翻倒或傾斜。
一請勿在浴缸、花灑或游泳池周圍使用本產品。在浴室使用時切勿平放於桌面/地上。
一禁止將產品浸入水中。
一嚴禁用細的金屬絲或其它異物插入機內任何孔隙，以免造成觸電事故。
一產品在使用時電源線應置於機體後面，放到機體前面會使其過熱而損壞，甚至發生安全事故。

產品結構



① 指示燈
② 手柄 *
③ 檔位旋鈕
④ 出風口
⑤ 掛勾
⑥ 濾網

* 手柄可旋轉 140°，最大承重量為 1kg。

使用說明

開機

1. 插上電源插頭，旋轉檔位旋鈕，選擇所需的功能：
   可在涼風、低暖、高暖; 3 種功能間切換使用。
2. 指示燈只有在工作狀態下才會點亮。



關閉取暖器

1. 將檔位旋鈕旋轉至⏻位置。
2. 拔下電源插頭，待整機冷卻後，將產品收好。
3. 為了產品的安全，延長使用壽命，關機前最好在涼風狀態工作
   15~30 秒，以便讓機內零件充分冷卻。

過熱安全保護

一當使用環境出現異常或使用不當導致產品內部溫度過高時，溫控元件會自動**切斷電源，產品停止工作。**

一待機件冷卻及排除異常後，可恢復正常使用。

一請勿將出風口過於貼近地面、牆壁或其他物件，出風口與任何障礙物應保持最少 50 厘米的安全距離。



安裝說明

一本產品在浴室使用時必須安裝牆上；於家居及睡房使用時可平放於桌面 / 地上或懸掛牆上使用。
一產品四週請預留足夠空間以作通風。

一．桌面 / 地上使用

將產品放在桌面或地上使用時，手柄需旋轉至整機後方。



注意：

一應與週邊物品保持安全距離，不要靠近易燃物品。
一請勿在浴缸、花灑或游泳池周圍使用本產品。在浴室使用時切勿平放於桌面 / 地上。

二 . 懸掛使用

1. 將產品背面的掛勾掛上毛巾架式通即可。
2. 如有需要，可垂下手柄。



注意：

—手柄最大承重量為 1kg。
—懸掛機身應離側面牆及其他物品 50cm 以上，產品安裝高度不低於 150cm。

三 . 掛牆使用

1. 在距離與地面最少 150cm 的牆上，使用定位紙在牆上劃下標記。
2. 用電鑽鑽兩個深度約 0.2-0.25cm、水平距離為 16.5cm、直徑為 0.6cm 的孔。



3. 再將螺絲塞套入孔內，再將螺絲固定螺絲塞中。
4. 將機背兩個掛孔位掛入預先鎖好的螺絲上，促使機器與螺絲孔位完全吻合。
5. 將機背的螺絲孔位對準螺釘，然後向右邊移動機身使產品固定。





注意：
一應與沐浴設備保持最少 60cm 的距離。

浴室使用說明

1. 本產品於浴室使用時必須安裝在牆上。
2. 此產品不能安裝於圖中著色範圍內。
3. 須確保正在浴缸區或淋浴區的人無法觸及開關和產品的其他部份，以免造成危險。
4. 手濕請勿接觸本產品。





清潔及保養

主機外殼及出風口

1. 在清洗之前，把插頭拔下，並讓產品冷卻。
2. 可用含少許中性洗滌劑的軟布輕擦，然後抹乾。不要用酒精、苯或塗料稀釋劑塗抹在本產品上。
3. 禁止用水直接沖洗機身。

濾網

1. 手扶著機身並捏著過濾網罩扣位，向上抬起至扣位鬆脫，並取下過濾網。
2. 清除掉過濾網上灰塵、毛髮後，放置水龍頭下方沖洗乾淨。
3. 待濾網晾乾後重新安裝濾網回機身。



疑難排解

問題	原因	解決方法
電源指示燈不亮 不工作	插頭沒有插好	檢查插頭是否正確插入插座內。
	未啟動電源	檔位旋鈕沒有旋轉到位， 檢查檔位旋鈕是否旋轉至接通位。 (詳見第 21 頁)
加熱時突然停機	機體過熱	溫度超過限溫器頂值，待機器冷卻後再使用。 (詳見第 22 頁)

產品參數

型號：	JNC-PBHTHK-WH
額定電壓：	220 - 240V~
產品頻率：	50 - 60Hz
額定輸入功率：	冷風 35W 暖風 1100W / 1900W
發熱元件：	PTC 陶瓷發熱器
電線長度：	2.5 m
產品尺寸：	37.2 x 29.5 x 13.7 cm
產品淨重：	1.76 kg
製造國：	中國

CB IPX2

保養條款

產品型號：JNC-PBHTHK-WH

多謝閣下購買及使用本公司產品，請參閱下列保養條款：

1. 本公司為客戶提供由購買日期後為期兩年的自攜保養服務。
2. 客戶請於指定辦公時間內自攜產品到本公司維修部及於修妥後取回產品。本公司不設上門維修服務。
3. 保養維修服務時，客戶必須出示有效之正本單據，保養條款方能生效，影印或傳真副本之單據恕不受理。倘未能出示正本，客戶須繳付維修服務費。
4. 保養範圍只包括主機硬件保養服務，不包括一切配置及附件：如機殼、插頭、配件、接駁及電源線（有關配置及附件之說明，請參照說明書）。
5. 在保養期內，所有更換的零件、配置及附件，均歸屬本公司所有，本公司有權作出任何處理。
6. 在下列情況下本保養條款將自動失效，本公司有權拒絕維修該產品或向客人收取所有的維修費用：
   - 產品曾用於工業或商業用途
   - 產品曾被非本公司維修人員拆開、修理、更換及改動
   - 產品曾因被錯誤操作，不適當使用、疏忽、輸入不合適電壓、人為損壞、意外、天災及不按使用說明書指示而導致損壞
   - 產品曾因震盪及碰撞、受沙或液體引致損壞
   - 不按照原廠提供之指示安裝或使用
   - 產品上的產品編號或規格貼紙被刪改
7. 本公司將不會為任何間接或相應的損失、利潤的損失或資料的流失負責。
8. 保養維修服務只在香港區內有效。
9. 保養條款的發出及終止權均屬本公司所有。就不明的情況或個案，經審查後，本公司有權終止服務。
10. 本公司保留修改保養條款之權利。

百家企業國際集團有限公司

如有任何疑問，請致電 100 客戶服務熱線 (852) 2342 9712 或
電郵 cs@jnc.com.hk，或於辦公時間親臨 100 客戶服務中心：

牛頭角偉業街 139 號 兆發大廈 4 樓 403 室 (牛頭角港鐵站 B6 出口)
營業時間：星期一至星期五 一早上 10 時至下午 6 時 (星期六、日及公眾假期休息)

JNC.com.hk



JNC◇ IPX2 防水暖爐

JNC-PBHTHK-WH

Instruction for using at bathroom

1. The product must be fixed on the wall.
2. The product can only be installed beyond the colored area in the picture.
3. It must be installed so that knob and other parts of product cannot be reached by a person who is in bathtub or shower.
4. Do not touch with wet hand.





Safety Notes

- It should be at least 60cm away from the water source.
- The minimum height above ground should be at least 1.5m.
- Maintain a distance of at least 50 cm between the air outlets and walls or any other objects.
- Leave enough space on all sides to allow adequate ventilation.
- Do not use the product in the immediate surroundings of a bathtub, a shower or swimming pool.
- Do not use the product if it has been dropped or if there is visible damage.

浴室使用說明

1. 本產品於浴室使用時必須安裝在牆上。
2.此產品不能安裝於圖中著色範圍內。
3. 須確保正在浴缸區或淋浴區的人無法觸及開關和產品的其他部份，以免造成危險。
4. 手濕請勿接觸本產品。





安全需知

- 應與沐浴設備保持最少60cm的距離。
- 產品安裝高度不低於150cm。
- 懸掛機身應離側面牆及其他物品50cm以上。
- 產品四週請預留足夠空間以作通風。
- 請勿在浴缸、花灑或游泳池周圍使用本產品。
- 如產品曾掉落或發現明顯損毀，請立即停止使用。